

FABRIC INSTALLATION GUIDE

Remove

Insert the blade of a small screwdriver into a corner of the form.

1

Pry a corner of the fabric panel from the channel.

2

Grasp the panel with your thumb and forefinger.

3

Pull the panel from the retention channel.

4

Install

Begin in a corner. Insert about 2 inches of the fabric panel into the channel.

1

Do this on both sides of the corner and then repeat for all four corners.

2

On each side of the form frame, insert about 2 inches of the panel into the channel at the middle.

3

On each side of the frame, press the remainder of the panel into the channel working from the middle to the corners.

4

softformTM
L I G H T I N G

support@softformlighting.com 720-408-4694